

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2007



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
Canon	MD-110 DV					•									
	DC10	•				•									
	DC100	•													
	DC20	•				•									
	DC21/DC22	•				•									
	DC210/230					•									
	DC-220V	•													
	DC40	•													
	DC50	•				•									
	Elura 100	•													
	Elura 85	•				•									
	Elura 90	•				•									
	EOS 20D w/kit lens							•							
	EOS 30D w/small zoom							•	•						
	EOS 40D w/Compact zoom							•		•					
	EOS 5D w/compact zoom				•					•			•		
	EOS Digital Rebel Xti/400D w/ compact zoom			•			•	•			•	•			
	EOS Rebel XT/350D with kit lens		•	•			•	•			•	•		•	
	ES420V/8200/8400V/8600				•							•	•	•	
	ES75			•								•	•		
	ES8200				•							•	•		
	G30Hi/35Hi/45Hi											•	•		
	HG10	•											•		
	HR10		•			•									
	HV10		•												
	HV20		•			•									
	MV500/500i/550i/530i/600/600i/630i/650i		•												
	MV750i/730i/700i/700		•												
	MV800	•				•									
	MV830i	•				•									
	MV850i	•				•									
	MV890					•									
	MV900					•									
	MV930/940/950/960					•									
	MVX100i/150i													•	
	MVX1i		•												
	MVX250i/200i/200	•										•			
	MVX25i/20i		•									•			
	MVX2i		•												
	MVX330i	•				•									
	MVX35i/30i		•												
	MVX430					•									
	MVX450/460					•									
	Optura 10/20														•
	Optura 100MC		•												
	Optura 30/40		•												•
	Optura 300/MVX10i		•												
	Optura 50		•			•									
	Optura 60		•			•									
	Optura Pi		•									•			
	Optura Xi/MV3Xi														•
	PowerShot G6	•													
	PowerShot S2 IS	•				•				•					

1=Best Fit, 2=Great Fit, 3=Fits

*Availability may vary by country or location

Updated 10/19/2007;Page 1 of 9

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2007



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
	PowerShot S3 IS	•				•					•				
	PowerShot S5 IS		•			•									
	V60HI/65Hi/75Hi				•									•	
	VC-C4		•										•		
	ZR10/20/25/30/45MC		•												
	ZR100	•				•									
	ZR200	•				•									
	ZR60/65MC/70MC		•												
	ZR80/85/90		•												
	ZR800					•									
	ZR830/850					•									
Epson	R-D1		•										•		
Fuji	FinePix F5 Pro w/compact zoom									•			•		
	FinePix S5 Pro w/compact zoom									•					
	FinePix S5700	•				•									
	FinePix S5800	•				•									
	FinePix S6000		•			•					•		•		
	FinePix S6500fd		•			•					•		•		
	FinePix S6900		•			•					•		•		
	FinePix S700		•			•					•		•		
	FinePix S8000fd	•				•					•		•		
	FinePix S9100/9600		•			•					•		•		
	FinePix S9500		•			•					•		•		
Hitachi	DZ-BX37E		•												
	DZ-GX3100E		•			•									
	DZ-GX3200E		•			•									
	DZ-GX3300A		•												
	DZ-GX5020A/5080A		•			•									
	DZ-MV100A/ADO			•									•		
	DZ-MV200		•										•		
	DZ-MV230		•										•		
	DZ-MV230A/270A/270E		•												•
	DZ-MV380		•												
	DZ-MV550/MV580		•				•								
	DZ-MV730A		•			•									
	DZ-MV780A	•				•									
	HS300A/500A		•			•									
	M2L		•												
	VMD 865LA/VMH 665/675LA													•	
	VMD 875/975LA													•	

1=Best Fit, 2=Great Fit, 3=Fits

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2007



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW	
JVC	Everio GZ-MG155/255	•				•										
	Everio GZ-MG26	•														
	Everio GZ-MG27/30/37/77	•				•										
	Everio GZ-MG555U	•				•										
	Everio GZ-MG57EK	•				•										
	Everio GZ-MG77U	•				•										
	GR-AX970													•		
	GR-AXM18													•		
	GR-D200/D23/D53			•												
	GR-D20EK/D50EK			•									•			
	GR-D230	•														
	GR-D250						•									
	GR-D30/70/90US			•												
	GR-D33/72/93	•														
	GR-D350AA						•									
	GR-D370	•					•									
	GR-D650	•					•									
	GR-D72	•					•									
	GR-D73US	•					•						•			
	GR-D750/770/796	•					•									
	GR-DF430US	•					•									
	GR-DV2000U														•	
	GR-DV3000U/4000U														•	
	GR-DV700/DV800U														•	•
	GR-DVL120U												•			
	GR-DVL160/DVL367	•						•							•	
	GR-DVL320/520/720														•	
	GR-DVL725/767/820/920				•										•	
	GR-DVM76/96	•													•	
	GR-FX15EK/SX25/FXM39E/SXM49/SXM58														•	
	GR-SXM240/260/340/740														•	
	GR-SXM38														•	
	GR-X5			•			•							•		
	GR-XM250US/740U														•	
	GY-DV500US														•	
	GZ-HD7/HD7U									•					•	
	GZ-MG130	•														
	GZ-MG255	•					•									
	GZ-MG26	•					•									
	GZ-MG505HD	•					•									
	GZ-MG50S	•					•									
	JY-VS5200U														•	

1=Best Fit, 2=Great Fit, 3=Fits

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2007



	Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
Panasonic AG-EZ50														
AG-HSC1U														
DMC-FZ7														
DMC-LC1/LC1B														
DMC-LC5														
HDC-DX1														
HDC-FX5														
HDC-SD1/SD3														
Lumix DMC-FZ18														
Lumix DMC-FZ50														
Lumix DMC-FZ8														
Lumix DMC-L1 w/compact zoom														
Lumix DMC-L10 w/compact zoom														
NV-DS29														
NV-EX21														
NV-GS1/GS4/GS5														
NV-GS11B/15B														
NV-GS120B/200B														
NV-GS180														
NV-GS250/400B														
NV-GS27														
NV-GS280														
NV-GS320														
NV-GS500														
NV-GS70														
NV-GX7														
NV-MX300B														
PalMcam PV-SD4090														
PV-DC152/252/352														
PV-DV203														
PV-DV52/102/202/402														
PV-DV702														
PV-DV952														
PV-GS120/200														
PV-GS150														
PV-GS180														
PV-GS19														
PV-GS250														
PV-GS300														
PV-GS31														
PV-GS320														
PV-GS35														
PV-GS39														
PV-GS400														
PV-GS500														
PV-GS50S														
PV-GS55														
PV-GS80/85														
PV-GS9/12/14/15														
PV-L352/452/552/652														
PV-L354/454														
PV-SD5000														
SDR-H18														

1=Best Fit, 2=Great Fit, 3=Fits

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2007



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
	VDR-D105					•									
	VDR-D210/230			•		•							•		
	VDR-D250		•			•									
	VDR-D300		•												
	VDR-D310			•									•		
	VDR-M30/M50/M50B/M70/M70B			•											
	VDR-M53		•			•									
	VDR-M75	•				•									
Pentax	*ist D w/kit zoom				•			•				•			
	*ist DL w/kit zoom			•			•				•	•			
	*ist DS w/kit zoom			•			•				•	•			
	*st DS 2 w/kit zoom			•			•				•	•			
	K100D w/compact Zoom				•			•			•	•	•		
	K10D w/Compact Zoom				•						•	•			
	K110D w/compact zoom				•			•			•	•	•		
	Optio MX/MX4					•									
Polaroid	PhotoMAX PDC 700		•												
RCA	CDS4100		•												
	CDS6300		•												
Ricoh	Caplio 400G Wide		•												
	Caplio 500G Wide		•												
	Caplio G3/G4	•													
Rollei	d-24/d-30/d-530 Flex			•			•						•		
	Prego dk4010	•													

1=Best Fit, 2=Great Fit, 3=Fits

*Availability may vary by country or location

Updated 10/19/2007;Page 6 of 9

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2007



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
Samsung	Digimax Pro 815		•		•							•	•		
	GX-10 w/compact zoom				•			•					•	•	
	GX-1L w/compact zoom			•	•							•	•	•	
	GX-1X w/compact zoom			•	•								•	•	
	SCD103/D107		•												
	SC-D173U	•				•									
	SCD180		•												•
	SCD23/27/67/VP-D10			•									•	•	
	SCD353	•													
	SCD363	•													
	SC-D372	•					•								
	SC-D575	•					•								
	SCD590														•
	SCD6040 DuoCam		•												
	SCD6550 DuoCam	•					•								
	SCL610/650					•								•	
	SCL700/770, SCW62					•								•	
	SCL906					•								•	
	SC-X105L					•								•	
	VP-D10				•								•		
	VP-D101/D103				•										
	VP-D130		•												
	VP-D230/D270i				•		•								
	VP-D323/D325i										•				
	VP-D361i	•					•								
	VPD5000i		•											•	
	VP-D6040i/D6050i		•						•						
	VP-D80i				•					•					•
	VP-D907i	•					•								
	VP-D963 WI						•								
	VP-D97	•	•										•		
	VP-DX10	•					•								
	VP-HMX10X						•								
VP-W90/VPL700/VPL900					•				•					•	
Sanvo	IDC-1000z		•										•		
Sharp	VL-AH161U/A111H													•	
	VL-AX1H/AX1U													•	
	VL-MC500H/500U		•										•		•
	VL-NZ55U/105U		•										•		•
	VL-Z1U/Z3U/Z5H/Z7U		•										•		
	VLZ900H		•					•					•		

1=Best Fit, 2=Great Fit, 3=Fits

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2007



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
Sony	Alpha DSLR-A100 w/compact zoom				•			•				•	•	•	
	Alpha DSLR-A100K w/compact zoom				•		•					•	•	•	
	CCD-TRV108/308/318/608														
	CCD-TRV138			•	•								•	•	
	CCD-TRV128/328												•		
	DCR-DVD100/200/300		•												•
	DCR-DVD101/201/301		•												
	DCR-DVD105	•													
	DCR-DVD108		•			•									
	DCR-DVD203E		•			•									
	DCR-DVD205/305	•													
	DCR-DVD308		•			•									
	DCR-DVD403E		•			•									
	DCR-DVD405		•			•									
	DCR-DVD408/508		•			•							•		
	DCR-DVD505		•												
	DCR-DVD605		•												
	DCR-DVD705		•												
	DCR-DVD92E	•				•									
	DCR-HC1000/HC100D			•									•		•
	DCR-HC14E	•					•								
	DCR-HC21E					•									
	DCR-HC28					•									
	DCR-HC38/46/HC48					•									
	DCR-HC42E					•									
	DCR-HC65/85/85E	•											•	•	•
	DCR-HC90E/96	•				•									
	DCR-IP220		•										•		•
	DCR-IP5/7BT														•
	DCR-IP55	•													
	DCR-PC1000E		•			•									
	DCR-PC101/105	•													•
	DCR-PC105E/106E/107E/109/109E	•													
	DCR-PC110		•												•
	DCR-PC120		•				•								
	DCR-PC330		•												
	DCR-PC350		•												
	DCR-PC8	•					•								
	DCR-SR100			•											
	DCR-SR-200/300	•				•									
	DCR-SR40	•				•									
	DCR-SR42/SR62/SR82	•				•									
	DCR-TRV128/328			•									•		
	DCR-TRV138			•		•							•		
	DCR-TRV140													•	
	DCR-TRV18/25/27			•										•	•
	DCR-TRV19/22/33	•													
	DCR-TRV240/340													•	
	DCR-TRV280			•		•							•		
	DCR-TRV38			•									•	•	
	DCR-TRV480			•		•							•		
	DCR-TRV50/80			•										•	•
	DCR-TRV530													•	

1=Best Fit, 2=Great Fit, 3=Fits

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2007



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
	DCR-TRV740/840														
	DCR-TRV950														
	DSC-F828			•			•					•		•	
	DSC-H1, H2, H5		•			•					•				
	DSC-H7/H9		•			•					•				
	DSC-R1				•				•			•	•		
	DSR-PDX10													•	
	HDR-CX7		•			•									
	HDR-HC1								•					•	
	HDR-HC3		•										•		
	HDR-HC5		•			•							•		
	HDR-HC7		•			•							•		
	HDR-SR1			•									•		
	HDR-SR5/SR7		•			•							•		
	HDR-UX1			•									•		
	HDR-UX5/UX7			•									•		
	MVC-CD350		•			•									
	MVC-CD500			•		•									
	MVC-FD200		•			•									
Thomson	VMD-160/170	•					•								
	VMD-270						•								
Toshiba	PDR-M700	•													
Vivitar	Vivicam V3500	•													

1=Best Fit, 2=Great Fit, 3=Fits

*Availability may vary by country or location