



Canon	Lens Case 1M	Lens Case 1S	Lens Case 1W	Lens Case 1N	Lens Case 1	Lens Case 2s	Lens Case 2	Lens Case 3	Lens Case 4S	Lens Case 4	Lens Case 5S	Lens Case 5	Lens Trekker 600 AW
EF 14mm f2.8L USM		*		*									
EF 15mm f2.8 fisheye	*												
EF 20mm f2.8 USM		*											
EF 24mm f1.4L USM					*								
EF 24mm f2.8	*												
EF 28mm f1.8 USM	*												
EF 28mm f2.8	*												
EF 35mm f1.4L USM					*								
EF 35mm f2	*												
EF 50 f1.4 USM	*												
EF 50mm f1.8 II	*												
EF 50mm f2.5 Macro	*												
EF-S 60mm f2.8 USM Macro	*												
EF 85mm f1.2L USM			*										
EF 85mm f1.8 USM	*												
EF 100mm f2 USM	*												
EF 100mm f2.8 USM Macro						*							
EF 135mm f2 USM					*								
EF 135mm f2.8 Soft-Focus				*									
EF 180mm f3.5L USM Macro				*				*					
EF 200mm f2.8L USM					*								
EF 300mm f2.8L USM						*							
EF 300mm f4L IS USM										*		*	
EF 400mm f2.8L IS USM										*		*	*
EF 400mm f4 DO IS USM												*	*
EF 400mm f5.6 USM												*	*
EF 500mm f4L USM												*	*
EF 600mm f4L USM												*	*
EF-S 10-22mm f3.5-4.5 USM					*								
EF-S 17-55mm f2.8 IS USM			*										
EF-S 18-55mm f3.5-5.6				*									
EF-S 18-55mm f3.5-5.6 IS				*									
EF 16-35mm f2.8L USM				*									
EF 16-35mm f2.8L II USM			*		*								
EF 17-35mm f2.8L USM			*		*								
EF 17-40mm f4L USM				*	*								
EF 17-85mm f4-5.6 USM				*	*								
EF 18-55mm f3.5-5.6 USM	*			*	*								
EF 20-35mm f3.5-4.5				*	*								
EF 22-55mm f4-5.6 USM (for APS)		*											
EF 24-70mm f2.8L USM		*	*		*								
EF 24-85mm f3.5-4.5 USM	*			*	*								
EF 24-105mm f4L IS USM				*	*								
EF 28-70mm f2.8L			*		*								
EF 28-80mm f3.5-5.6 II		*			*								
EF 28-80mm f3.5-6.6 V USM		*			*								
EF 28-90mm f4-5.6 II / USM	*				*								
EF 28-105mm f3.5-4.5 II USM		*			*								
EF 28-105mm f4-5.6 / USM	*				*								
EF 28-135mm f3.5-5.6 IS USM					*								
EF 28-200mm f3.5-5.6 / USM					*								
EF 28-300mm f3.5-5.6L IS USM								*					
EF 35-80mm f4-5.6 III	*								*				
EF 35-135mm f4-5.6 USM				*									
EF 35-350mm f3.5-5.6L USM				*				*					
EF 55-200mm f4.5-5.6 II USM				*				*					
EF 55-250mm f4.5-5.6 IS				*				*					
EF 70-200mm f2.8L USM								*					
EF 70-200mm f2.8L IS USM								*					
EF 70-200mm f4L USM							*	*					
EF 70-300mm f4-5.6 IS USM						*		*					
EF 70-300mm f4.5-5.6 DO IS USM			*					*					
EF 75-300mm f4-5.6 III / USM						*		*					
EF 75-300mm f4-5.6 IS USM						*		*					
EF 80-200mm f2.8L USM							*	*					
EF 80-200mm f4.5-5.6 II		*						*					
EF 90-300mm f4.5-5.6 USM					*			*					
EF 100-300mm f4.5-5.6 USM				*				*					
EF 100-400mm f4.5-5.6L IS USM				*				*					
TS-E 24mm f3.5L Tilt & Shift					*			*					
TS-E 45mm f2.8 Tilt & Shift					*			*					
TS-E 90mm f2.8 Tilt & Shift		*			*			*					
MP-E65 f2.8 1-5x Macro			*					*					
Extender 1.4x II	*							*					
Extender 2x II	*							*					

*Availability may vary depending on country and location



	Lens Case 1M	Lens Case 1S	Lens Case 1W	Lens Case 1N	Lens Case 1	Lens Case 2s	Lens Case 2	Lens Case 3	Lens Case 4S	Lens Case 4	Lens Case 5S	Lens Case 5	Lens Trekker 600 AW
Konica-Minolta	16mm f2.8 fisheye		*										
	20mm f2.8		*										
	24mm f2.8		*										
	28mm f2		*										
	28mm f2.8		*										
	35mm f1.4 G		*										
	35mm f2		*										
	50mm f1.4		*										
	50mm f1.7		*										
	50mm f2.8 (D) Macro		*										
	50mm f3.5 Macro		*										
	85mm f1.4 G (D)		*										
	100mm f2.8 (D) Macro				*	*							
	100mm f2.8 Soft Focus		*										
	135mm f2.8 STF					*							
	200mm f2.8 APO G							*					
	200mm f4 APO G Macro								*				
	300mm f2.8 APO G (D) SSM								*				*
	300mm f4 APO G										*		*
	400mm f4.5 APO G											*	*
	600mm f4 APO G												*
	500mm f8 REFLEX (mirror)										*		
	17-35mm f2.8-4 (D)					*							
	17-35mm f3.5 G					*							
	20-35mm f3.5-4.5		*	*		*							
	24-50mm f4	*											
	24-85mm f3.5-4.5		*										
	24-105mm f3.5-4.5 (D)	*											
	28-70mm f2.8 G					*							
	28-75mm f2.8 (D)				*								
	28-80mm f3.5-5.6					*							
	28-100mm f3.5-5.6 (D)		*			*							
	35-80mm f4-5.6 II		*			*							
	70-200 f2.8 APO G (D) SSM								*				
	70-210mm f4.5-5.6 II					*							
	75-300mm f4.5-5.6 (D)					*							
	100-300mm f4.5-5.6 APO (D)					*							
	100-400 f4.5-6.7 APO							*					
	Macro Zoom 3x-1x f1.7-2.8					*							
	Teleconverter 1.4x (D) APO	*											
	Teleconverter 2x (D) APO	*											
	10.5mm f2.8G DX Fisheye	*											
	14mm f2.8					*							
	16mm f2.8D	*											
	18mm f2.8					*							
20mm f2.8	*												
24mm f2.8D	*												
28mm f1.4D		*											
35mm f2D	*												
AF 60mm f2.8D Micro	*												
AF 85mm f1.4					*								
AF 85mm f1.8	*												
AF DC 105mm f2				*									
AF 105mm f2.8 Micro			*										
AF DC 135mm f2						*							
AF 180mm f2.8						*							
AF-S 200mm f2G ED-IF VR										*			
AF 200 f4 Micro								*					
AF-S 300mm f2.8 VR								*				*	
AF-S 300mm f2.8D ED-IF II										*		*	
AF-S 300mm f2.8										*		*	
AFI 300mm f2.8										*		*	
AF-S 300mm f4 ED-IF								*				*	
AF-S 600mm f4												*	
AF-S 500mm f4												*	
AF-S 400mm f2.8												*	
AF-S DX 12-24mm f4 G					*							*	
AF-S 17-35mm f2.8					*							*	
AF-S DX 17-55mm f2.8 G					*							*	
AF 18-35mm f3.5-4.5					*							*	
AF-S DX 18-70mm f3.5-4.5 G		*			*							*	
AF-S DX 18-135mm f3.5-5.6G ED-IF				*								*	
AF-S DX 18-200mm f3.5-5.6G ED-IF VR II			*									*	
AF 24-50mm f3.3-4.5	*		*										
AF 24-85 f2.8-4					*								
AF-S 24-85mm f3.5-4.5	*												

*Availability may vary depending on country and location



AF 24-120mm f3.5-5.6



Lens Case 1M



Lens Case 1S



Lens Case 1W



Lens Case 1N



Lens Case 1



Lens Case 2s



Lens Case 2



Lens Case 3



Lens Case 4S



Lens Case 4



Lens Case 5S



Lens Case 5



Lens Case 5



Lens Trekker 600 AW



	Lens Case 1M	Lens Case 1S	Lens Case 1W	Lens Case 1N	Lens Case 1	Lens Case 2s	Lens Case 2	Lens Case 3	Lens Case 4S	Lens Case 4	Lens Case 5S	Lens Case 5	Lens Trekker 600 AW
Nikon (AF)	Continued												
AF-S 24-120mm f3.5-5.6 G ED-IF VR													
AF-S 28-70mm f2.8													
AF 28-80mm f3.3-5.6													
AF 28-100mm f3.5-5.6													
AF 28-105mm f3.5-4.5													
AF 28-200mm f3.5-5.6G													
AF 35-70mm f2.8													
AF 35-105mm 3.5-4.5D													
AF-S 55-200mm 4.5-5.6G ED-IF VR													
AF 70-180 f4.5-5.6 Micro													
AF-S 70-200 f2.8G IF-ED VR													
AF-S 70-300 f4.5-5.6G VR ED-IF													
AF 70-300mm f4-5.6													
AF 70-300mm f-5.6G													
AF 75-240mm f4.5-5.6D													
AF 80-200 f2.8D ED													
AF-S 80-200mm f2.8G													
AF 80-400mm f4.5-5.6 VR													
AF-S 200-400mm f4G VR													
PC 85mm f2.8D													
TC-17E II 1.7x Converter													
TC-14E II 1.4x Converter													
TC-20E II 2x													
Nikon (MF)													
15mm f3.5													
18mm f3.5													
20mm f2.8													
24mm f2													
24mm f2.8													
28mm f2													
28mm f2.8													
28mm f3.5 PC													
35mm f1.4													
35mm f2													
45mm f2.8													
50mm f1.2													
50mm f1.4													
50mm f1.8													
55mm f2.8 Micro													
85mm f1.4													
105mm f1.8													
105mm f2.5													
105mm f2.8 Micro													
135mm f2.8													
180mm f2.8													
200mm f2													
200mm f4 Micro													
400mm f2.8													
400mm f3.5													
400mm f5.6													
500mm f4													
500mm f8 Reflex (mirror)													
600mm f5.6													
1000mm f1.1 reflex (mirror)													
28-85mm f3.5-4.5													
35-70mm f3.3-4.5													
35-105mm f3.5-4.5													
35-135mm f3.5-4.5													
35-200mm f3.5-4.5													
70-210mm f4.5-5.6													
100-300mm f5.6													
TC14A 1.4x Converter													
TC14B 1.4x Converter													
TC201 2x Converter													
TC301 2x Converter													



	Lens Case 1M	Lens Case 1S	Lens Case 1W	Lens Case 1N	Lens Case 1	Lens Case 2s	Lens Case 2	Lens Case 3	Lens Case 4S	Lens Case 4	Lens Case 5S	Lens Case 5	Lens Trekker 600 AW
Olympus E-Series													
7-14mm F4 ED													
EZ 11-22mm f2.8-3.5													
14-45mm f3.5-5.6		•											
14-54mm f2.8-3.5					•								
18-180mm F3.5-6.3		•											
35-100mm F2 PRO ED													
40-150mm f3.5-4.5													
50-200mm f2.8-3.5 ED													
90-250mm F2.8 PRO ED													
8mm Fisheye f3.5 ED													
50mm f2 ED Macro	•												
150mm f2 ED													
300mm f2.8 ED													
EC14 1.4x Converter	•												
EX25 Extension Tube	•												
Pentax (MF)													
15mm f3.5													
16mm f2.8 fisheye		•											
20mm f2.8	•												
28mm f3.5 Shift													
50mm f1.2	•												
200mm f2.8 ED													
300mm f2.8 ED (IF)													
500mm f4.5													
400mm f2.8 ED (IF)													
400mm f5.6													
1000mm f11 mirror													
35-80mm f4-5.6	•												
Pentax AF													
F Series													
31mm f1.8 FA AL Limited	•												
43mm f1.9 FA Limited	•												
77mm f1.8 FA Limited	•												
50mm f2.8 FA Macro	•												
100mm f2.8 FA Macro													
100mm f3.5 FA Macro	•												
17-28mm f3.5-4.5													
35-80mm f4-5.6													
80-200mm f4.7-5.6													
100-300mm f4.5-5.6													
100-300mm f4.7-5.8 FA													
Pentax AF													
14mm f2.8 ED													
20mm f2.8	•												
24mm f2 AL (IF)	•												
28mm f2.8 AL													
35mm f2 AL	•												
50mm f1.4	•												
50mm f1.7	•												
85mm f1.4 (IF)													
85mm f2.8 Soft Focus													
135mm f2.8 (IF)													
200mm f2.8 ED (IF)													
300mm f2.8 ED (IF)													
300mm f4.5 ED (IF)													
600mm f4 ED (IF)													
10-17mm f3.5-4.5 ED													
12-24mm F4 ED AL													
16-45mm f4 ED AL													
18-55mm F3.5-5.6 AL	•												
20-35mm f4 AL	•												
24-90 f3.5-4.5 AL	•												
28-200mm f3.8-5.6 AL (IF)													
28-70mm f2.8													
28-70mm f2.8 AL Power Zoom													
28-70mm f4 AL													
28-80mm f3.5-5.6													
28-90 f3.5-5.6	•												
28-105mm f4-5.6 Power Zoom													
70-200mm f4-5.6 Power Zoom													
75-300 f4.5-5.8 AL													
80-200mm f2.8 ED (IF)													
80-320mm f4.5-5.6													
250-600mm f5.6 ED (IF) Power Zoom													
1.7x Converter	•												
Sony													
SAL 50mm f/1.4	•												
SAL 18-200mm f/3.5-6.3 Aspherical ED													
SAL 75-300mm D f/4.5-5.6													

*Availability may vary depending on country and location



	Lens Case 1M	Lens Case 1S	Lens Case 1W	Lens Case 1N	Lens Case 1	Lens Case 2s	Lens Case 2	Lens Case 3	Lens Case 4S	Lens Case 4	Lens Case 5S	Lens Case 5	Lens Trekker 600 AW	
Sigma	8mm f3.5 EX DG Fisheye	•												
	8mm f4 EX Circular Fisheye	•												
	14mm f2.8 EX Aspherical / HSM					•								
	15mm f2.8 EX Diagonal Fisheye	•												
	20mm f1.8 DG Aspherical (RF)			•										
	24mm f1.8 EX DG Aspherical Macro					•								
	28mm f1.8 EX DG Aspherical Macro					•								
	30mm f1.4 EX DC-HSM AF	•												
	50mm f2.8 EX DG Macro	•												
	105mm f2.8 EX Macro				•									
	150mm f2.8 EX DG Macro / HSM									•				
	180mm f3.5 APO EX (IF) / HSM								•					
	300mm f2.8 EX DG HSM											•		
	500mm f4.5 EX DG													•
	600mm f8 Mirror									•				
	10-20mm f4-5.6 EX DC HSM					•								
	12-24mm f4.5-5.6 EX DSG Aspherical / HSM					•								
	15-30mm f3.5-4.5 EX DG Aspherical					•		•						
	17-35mm f2.8-4 EX Aspherical / HSM					•								
	18-50mm f2.8 EX DC				•									
	18-50mm f3.5-5.6 DC	•												
	18-50mm f3.5-5.6 DC HSM		•											
	18-125mm f3.5-5.6 DC		•											
	18-200mm f3.5-6.3 DC		•											
	18-200mm f3.5-6.3 DC OS					•								
	20-40mm f2.8 EX DG Aspherical			•										
	24-60mm f2.8 EX DG Aspherical			•										
	24-70mm f2.8 EX DG Macro			•										
	24-70mm f2.8 EX DG Aspherical DF			•										
	24-70mm f3.5-5.6 HF		•											
	24-135mm f2.8-4.5 Aspherical (IF)					•								
	28-70mm f2.8 EX DG				•									
	28-70mm f2.8-4 Compact Zoom	•												
	28-80mm f3.5-5.6 II Aspherical		•											
	28-105mm f2.8-4 Aspherical		•											
	28-105mm f3.8-5.6 UC III Aspherical (IF)		•											
	28-135mm f3.8-5.6 Aspherical (IF) Macro		•											
	28-200mm f3.5-5.6 Aspherical Compact Macro		•											
	28-300mm f3.5-6.3 Aspherical Macro Hyperzoom				•									
	50-150mm f2.8 EX DC HSM						•							
	50-500mm f4-6.3 APO EX (RF) HSM												•	
	55-200mm f4-5.6 DC/HSM					•								
	70-200mm f2.8 APO EX HSM								•					
	70-300mm f4-5.6 DL Macro Super II					•								
	70-300mm f4-5.6 APO Macro Super II					•								
80-400mm f4.5-5.6 APO EX OS											•			
100-300mm f4.5-6.7 DL					•									
100-300mm f4 APO EX (IF)										•				
120-300mm f2.8 APO EX (IF) HSM										•				
135-400mm f4.5-5.6 Aspherical (RF)								•				•		
170-500mm f5-6.3											•		•	
300-800mm f5.6 APO EX (IF) HSM													•	
Tamron	SP 14mm f2.8 Aspherical (IF)				•									
	SP 90mm f2.8 Di Macro				•									
	SP 180mm f3.5 Di LD (IF) Macro							•						
	SP 300mm f2.8 Aspherical (IF)													
	SP 11-18mm f4.5-5.6 DII LD					•						•		
	SP 17-35mm f2.8-4 Di LD Aspherical (IF)					•								
	AF 17-50mm f2.8 XR Di II				•									
	AF 18-200mm f3.5-6.3 XR DII LD													
	AF 19-35mm f3.5-4.5					•								
	SP-AF 20-40mm f2.7-3.5 IF					•								
	SP 24-70mm f3.5-5.6 LD F	•												
	SP 28-75mm f2.8-4 Di					•								
	SP 70-210mm 2.8 AF						•							
	AF 75-300 f4.5-6 LD Macro					•								
	200-400mm 5.6 LD F								•					
	SP 200-500mm f5-6.3 Di LD													
	XR 28-300mm f3.5-6.3 Di LD Aspherical (IF) Macro				•							•		
	SP 24-135mm f3.5-5.6 AD Aspherical (IF)					•								
	28-80mm f3.5-5.6 Aspherical	•												
	28-105mm f4.5-6 (IF)	•												
	SP 28-105mm f2.8 Aspherical (IF)					•								
	28-200mm f3.8-5.6 Aspherical (IF) Macro					•								
	70-300 f4.5-6 LD Macro					•								
	80-210mm f4-5.6					•								

*Availability may vary depending on country and location



100-300mm f5.6 F



Lens Case 1M



Lens Case 1S



Lens Case 1W



Lens Case 1N




Lens Case 1



Lens Case 2s



Lens Case 2



Lens Case 3



Lens Case 4S



Lens Case 4



Lens Case 5S



Lens Case 5



Lens Case 5



Lens Trekker 600 AW

		 Lens Case 1M	 Lens Case 1S	 Lens Case 1W	 Lens Case 1N	 Lens Case 1	 Lens Case 2s	 Lens Case 2	 Lens Case 3	 Lens Case 4S	 Lens Case 4	 Lens Case 5S	 Lens Case 5	 Lens Trekker 600 AW	
Tokina	AT-X 12-24mm f4 AF Pro					•									
	AT-X 19-35mm f3.5-4.5 (IF)					•									
	AT-X 24-200 f3.5-5.6 (IF)					•									
	AT-X 80-400mm f4.5-5.6 (IF) II									•					
	AT-X PRO 20-35mm f2.8					•									
	AT-X PRO 28-70mm f2.8 SV					•									
	AT-X PRO 28-80mm f2.8					•									
	AT-X PRO 80-200mm f2.8								•						
	AT-X 100-300mm f4 AF II											•			
	AT-X PRO 300mm f2.8											•			
SZ-X 28-200mm f3.5-5.3				•											