











LOWEPRO NAPOLI SERIES MATRIX 6-2009

		 Napoli 5	 Napoli 10	 Napoli 20	 Napoli 30
Argus	DC-6340		•		
BenQ	C840			•	
	DC C1050			•	
	DC C740i			•	
	DC C750			•	
	DC C820		•		
	DC C850			•	
	DC E100			•	
	DC E800		•		
Canon	Digital IXUS 80		•		
	IXUS 70		•		
	IXY Digital 820IS		•		
	PowerShot A1000 IS			•	
	PowerShot A1100 IS			•	
	PowerShot A480			•	
	PowerShot A570 IS				•
	PowerShot A580				•
	PowerShot A590 IS				•
	PowerShot SD1000/IXUS 70	•			
	PowerShot SD1100 IS/IXUS 80		•		
	PowerShot SD1200 IS		•		
	PowerShot SD770/IXUS 85		•		
	PowerShot SD780 IS	•			
	PowerShot SD790 IS/IXUS 90 IS		•		
	PowerShot SD850 IS/IXUS 950 IS			•	
	PowerShot SD870 IS/IXUS 860 IS			•	
	PowerShot SD880 IS/IXUS 870 IS			•	
	PowerShot SD890 IS/IXUS 970 IS			•	
	PowerShot SD950 IS/Digital IXUS 960 IS			•	
	PowerShot SD970 IS			•	
	PowerShot TX-1				•
	SD1200 IS		•		
SD850IS/Ixus 950IS		•			
Casio	EXILIM EX-S10		•		
	EXILIM EX-S12		•		
	EXILIM EX-S880			•	
	EXILIM EX-V7/V8			•	
	EXILIM EX-Z100		•		
	EXILIM EX-Z1080		•		
	EXILIM EX-Z11		•		
	EXILIM EX-Z200		•		
	EXILIM EX-Z250			•	
	EXILIM EX-Z300			•	
	EXILIM EX-Z400			•	
	EXILIM EX-Z80		•		
	EXILIM EX-Z85			•	
	EXILIM EX-Z850		•		
	EXILIM EX-Z9		•		






LOWEPRO NAPOLI SERIES MATRIX 6-2009

					
		Napoli 5	Napoli 10	Napoli 20	Napoli 30
DXG	110			•	
	305V				•
	568				•
Fuji	FinePix A100/A150			•	
	FinePix A820/A825/A900			•	
	FinePix A850			•	
	FinePix A920			•	
	FinePix F100fd			•	
	FinePix F200EXR			•	
	FinePix F40fd			•	
	FinePix F47fd			•	
	FinePix F480			•	
	FinePix F50fd/F60fd		•		
	FinePix J10/J20		•		
	FinePix J100/J110W/J120W/J150W		•		
	FinePix J12/J50		•		
	FinePix Z10fd/Z100fd/Z200fd		•		
	FinePix Z20fd		•		
	FinePix Z30fd		•		
	FinePix Z33		•		
	FinePix Z5fd		•		
GE	A730				•
	A735/A835		•		
	E1050		•		
	E840S			•	
	G2/G3			•	
HP	Photosmart E337			•	
	Photosmart E427		•		
	Photosmart M437			•	
	Photosmart M447			•	
	Photosmart M537			•	
	Photosmart M547			•	
	Photosmart M627			•	
	Photosmart M637			•	
	Photosmart M737			•	
	Photosmart Mz67			•	
	Photosmart R742		•		






LOWEPRO NAPOLI SERIES MATRIX 6-2009

					
		Napoli 5	Napoli 10	Napoli 20	Napoli 30
Kodak	EasyShare C180			•	
	EasyShare C513			•	
	EasyShare C603			•	
	EasyShare C613			•	
	EasyShare C653			•	
	EasyShare C703			•	
	EasyShare C713			•	
	EasyShare C763		•		
	EasyShare C913			•	
	EasyShare M1033		•		
	EasyShare M1063		•		
	EasyShare M1073 IS			•	
	EasyShare M1093 IS			•	
	EasyShare M753/M853				•
	EasyShare M763/M863		•		
	EasyShare M873/M883		•		
	EasyShare M893 IS			•	
	EasyShare Picture Viewer	•			
	EasyShare V1073/V1273		•		
	EasyShare V1285			•	
	EasyShare Z1085 IS				•
	EasyShare Z1275			•	
	EasyShare Z1285			•	
	EasyShare Z1485 IS				•
EasyShare Z885			•		
Leica	C-Lux 1		•		
	C-Lux 3		•		
Minox	DC 7022		•		
	DC-8011		•		
Mustek	GSmart D35			•	
Nikon	Coolpix L14/L15			•	
	Coolpix L16/L18			•	
	Coolpix S200	•			
	Coolpix S202	•			
	Coolpix S210	•			
	Coolpix S220	•	•		
	Coolpix S51/S51c		•		
	Coolpix S510		•		
	Coolpix S52		•		
	Coolpix S520		•		
	Coolpix S52c		•		
	Coolpix S550		•		
	Coolpix S560		•		
	Coolpix S60			•	
	Coolpix S600		•		
	Coolpix S620		•		
	Coolpix S700		•		
	Coolpix S710		•		

LOWEPRO NAPOLI SERIES MATRIX 6-2009

		 Napoli 5	 Napoli 10	 Napoli 20	 Napoli 30
Olympus	FE-190			•	
	FE-20			•	
	FE-25			•	
	FE-280		•		
	FE-290			•	
	FE-300		•		
	FE-3000/3010		•		
	FE-310			•	
	FE-320		•		
	FE-350			•	
	FE-360		•		
	FE-370		•		
	FE-45			•	
	FE-5000/5010			•	
	Mju 1040	•			
	Mju 1050SW			•	
	Mju 1060			•	
	Stylus 1030SW			•	
	Stylus 1040	•			
	Stylus 1050SW			•	
	Stylus 1200/Mju Digital 1200		•		
	Stylus 550WP/Mju 550WP			•	
	Stylus 7000/Mju 7000			•	
	Stylus 770SW		•		
	Stylus 780		•		
	Stylus 790SW/Mju 790SW			•	
	Stylus 830/Mju Digital 830			•	
	Stylus 840		•		
	Stylus 850SW			•	
	Stylus Tough 8000/Mju 8000			•	
	X835		•		

LOWEPRO NAPOLI SERIES MATRIX 6-2009

		 Napoli 5	 Napoli 10	 Napoli 20	 Napoli 30
Panasonic	Lumix DMC- FX07		•		
	Lumix DMC-FS12/FS62			•	
	Lumix DMC-FS15			•	
	Lumix DMC-FS20			•	
	Lumix DMC-FS25			•	
	Lumix DMC-FS3/FS5			•	
	Lumix DMC-FS42			•	
	Lumix DMC-FS6			•	
	Lumix DMC-FS7			•	
	Lumix DMC-FX100			•	
	Lumix DMC-FX150			•	
	Lumix DMC-FX33		•		
	Lumix DMC-FX35		•		
	Lumix DMC-FX37		•		
	Lumix DMC-FX40/FX48		•		
	Lumix DMC-FX500			•	
	Lumix DMC-FX55		•		
	Lumix DMC-FX550/FX580		•		
	Lumix DMC-LS60/LS75			•	
Lumix DMC-LS80			•		
Lumix DMC-TS1/FT1			•		
Pentax	Optio A30		•		
	Optio A40		•		
	Optio E40			•	
	Optio E50			•	
	Optio E70			•	
	Optio L30		•		
	Optio M30		•		
	Optio M40		•		
	Optio M50/M60			•	
	Optio P70			•	
	Optio S10		•		
	Optio S12	•			
	Optio T30		•		
	Optio V10		•		
Optio Z10			•		
Polaroid	A310			•	
	i533P		•		
	i631			•	
	i633			•	
	i733			•	
	i832W			•	
Ricoh	Caplio RR770			•	

LOWEPRO NAPOLI SERIES MATRIX 6-2009

		 Napoli 5	 Napoli 10	 Napoli 20	 Napoli 30
Sony	DSC-G1				•
	DSC-S650/S700/S800			•	
	DSC-S730			•	
	DSC-S750/S780		•		
	DSC-S950			•	
	DSC-S980		•		
	DSC-T100	•			
	DSC-T2	•			
	DSC-T20	•			
	DSC-T200		•		
	DSC-T300		•		
	DSC-T500			•	
	DSC-T70		•		
	DSC-T700		•		
	DSC-T90/T900		•		
	DSC-W110/W200			•	
	DSC-W115/W125		•		
	DSC-W120/W130		•		
	DSC-W150/W170		•		
	DSC-W210/W220			•	
	DSC-W300			•	
Vivitar	V6320			•	